

Eastwood[®]

DO THE JOB RIGHT.[®]

Item #20566

TIG200 DC WELDER

INSTRUCTIONS



TIG Welding is the most controllable, efficient and versatile method of welding many metals including steel, stainless steel and more. Your **EASTWOOD TIG 200 DC WELDER** with High-Frequency Inverter Technology is capable of welding thin or heavy gauge steel with precision and ease. The voltage self-sensing circuitry automatically detects a power source range of 110 to 240 volts and delivers from 10 up to 200 Amps DC. The included foot pedal provides the operator with the precise amperage control required when welding. A high frequency start feature guarantees an instant arc strike with no tungsten contamination.

STATEMENT OF LIMITED WARRANTY

The Eastwood Company (hereinafter "Eastwood") warrants to the end user (purchaser) of all new welding and cutting equipment (collectively called the "products") that it will be free of defects in workmanship and material. This warranty is void if the equipment has been subjected to improper installation, improper care or abnormal operations.

WARRANTY PERIOD:

All warranty periods begin on the date of purchase from Eastwood. Warranty Periods are listed below, along with the products covered during those warranty periods:

3 Year Warranty on Material, Workmanship, and Defects:

- Eastwood TIG 200 AC/DC Welder

Items not covered under this warranty: Collets, collet bodies, tungsten, nozzles, and ground clamp and cable.
All other components are covered by the warranty and will be repaired or replaced at the discretion of Eastwood.

2 Years:

- All Welding Helmets.

CONDITIONS OF WARRANTY TO OBTAIN WARRANTY COVERAGE:

Purchaser must first contact Eastwood at 1-800-345-1178 for an RMA# before Eastwood will accept any welder returns.

Final determination of warranty on welding and cutting equipment will be made by Eastwood.

WARRANTY REPAIR:

If Eastwood confirms the existence of a defect covered under this warranty plan, Eastwood will determine whether repair or replacement is the most suitable option to rectify the defect. At Eastwood's request, the purchaser must return, to Eastwood, any products claimed defective under Eastwood's warranty.

FREIGHT COSTS:

The purchaser is responsible for shipment to and from Eastwood.

WARRANTY LIMITATIONS:

EASTWOOD WILL NOT ACCEPT RESPONSIBILITY OR LIABILITY FOR REPAIRS UNLESS MADE BY EASTWOOD. EASTWOOD'S LIABILITY UNDER THIS WARRANTY SHALL NOT EXCEED THE COST OF CORRECTING THE DEFECT OF THE EASTWOOD PRODUCT. EASTWOOD WILL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES (SUCH AS LOSS OF BUSINESS, ETC.) CAUSED BY THE DEFECT OR THE TIME INVOLVED TO CORRECT THE DEFECT. THIS WRITTEN WARRANTY IS THE ONLY EXPRESS WARRANTY PROVIDED BY EASTWOOD WITH RESPECT TO ITS PRODUCTS. WARRANTIES IMPLIED BY LAW SUCH AS THE WARRANTY OF MERCHANTABILITY ARE LIMITED TO THE DURATION OF THIS LIMITED WARRANTY FOR THE EQUIPMENT INVOLVED. THIS WARRANTY GIVES THE PURCHASER SPECIFIC LEGAL RIGHTS.

THE PURCHASER MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.

SPECS

Function	Output Amperage Range	Maximum Output No Load Voltage	Input Voltage	Rated Duty Cycle	Pre Gas Flow	Post Gas Flow	Weight	Overall Dimensions
TIG	10-145A DC	56V DC	120VAC	60% @ 145 Amps	0.5 Sec	5 Sec	18 lbs. [8.16kg]	16.9" [430mm] x 7.3" [185mm] x 12" [306mm]
	10-200A DC		220VAC	60% @ 190 Amps				
STICK	10-140A		120VAC	60% @ 140 Amps	NA	NA		
	10-185A		220VAC	60% @ 185 Amps				

DUTY CYCLE

The rated Duty cycle refers to the amount of welding that can be done within an amount of time. The Eastwood TIG 200 DC has a duty cycle of 60% at 190 Amps. It is easiest to look at your welding time in blocks of 10 Minutes and the Duty Cycle being a percentage of that 10 Minutes. If welding at 190 Amps with a 60% Duty Cycle, within a 10 Minute block of time you can weld for 6 Minutes with 4 Minutes of cooling for the welder.

To increase the duty cycle you can turn down the Amperage Output control. Going above 190 Amps will yield a lower duty cycle.

SAFETY INFORMATION

⚠ DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

⚠ WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

⚠ CAUTION

CAUTION used with the safety alert symbol, indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

⚠ NOTICE

NOTICE is used to address practices not related to personal injury.



⚠ READ INSTRUCTIONS

- Thoroughly read and understand this manual before using.
- Save for future reference.



⚠ WARNING ELECTRIC SHOCK CAN CAUSE INJURY OR DEATH!

- Improper use of an electric welder can cause electric shock, injury and death! Read all precautions described in the Welder Manual to reduce the possibility of electric shock.
- Disconnect welder from power supply before assembly, disassembly or maintenance of the torch, contact tip and when installing or removing nozzles.
- Always wear dry, protective clothing and leather welding gloves and insulated footwear. Use suitable clothing made from durable flame-resistant material to protect your skin.
- If other persons or pets are in the area of welding, use welding screens to protect bystanders from sparks.
- Always operate the welder in a clean, dry, well ventilated area. Do not operate the welder in humid, wet, rainy or poorly ventilated areas.
- The electrode and work (or ground) circuits are electrically “hot” when the welder is on. Do not allow these “hot” parts to come in contact with your bare skin or wet clothing.
- Separate yourself from the welding circuit by using insulating mats to prevent contact from the work surface.
- Be sure that the work piece is properly supported and grounded prior to beginning an electric welding operation.
- Always attach the ground clamp to the piece to be welded and as close to the weld area as possible. This will give the least resistance and best weld.



⚠ WARNING WELDING SPARKS CAN CAUSE FIRE OR EXPLOSION!

- Electric welding produces sparks which can be discharged considerable distances at high velocity igniting flammable or exploding vapors and materials.
- Do not operate electric arc welder in areas where flammable or explosive vapors are present.
- Do not use near combustible surfaces. Remove all flammable items within 35 feet of the welding area.
- Always keep a fire extinguisher nearby while welding.
- Use welding blankets to protect painted and or flammable surfaces; rubber weather-stripping, dash boards, engines, etc.
- Ensure power supply has properly rated wiring to handle power usage.



⚠ WARNING ELECTROMAGNETIC FIELDS CAN BE A HEALTH HAZARD!

- The electromagnetic field that is generated during arc welding may interfere with various electrical and electronic devices such as cardiac pacemakers. Anyone using such devices should consult with their physician prior to performing any electric welding operations.
- Exposure to electromagnetic fields while welding may have other health effects which are not known.

SAFETY INFORMATION



⚠ WARNING FUMES & WELDING GASES CAN BE A HEALTH HAZARD!

- Fumes and gasses released during welding are hazardous. Do not breathe fumes that are produced by the welding operation. Wear an OSHA-approved respirator when welding.
- Always work in a properly ventilated area.
- Never weld coated materials including but not limited to: cadmium plated, galvanized, lead based paints.



⚠ WARNING BUILDUP OF GAS CAN INJURE OR KILL!

- Shut off shielding gas supply when not in use.
- Ensure adequate ventilation. Do not weld in confined spaces.
- Always turn your face away from valve outlet when opening cylinder valve.



⚠ WARNING CYLINDERS CAN EXPLODE IF DAMAGED!

Shielding gas cylinders contain gas under high pressure. If damaged, a cylinder can explode. As gas cylinders are a normal component of the welding process, use extra care to handle them carefully.

- Protect compressed gas cylinders from excessive heat, mechanical shocks, physical damage, slag, open flames, sparks and arcs. Keep away from any welding or other electrical circuits.
- Install cylinders in an upright position by securing to a specifically designed rack, cart or stationary support to prevent falling or tipping over.
- Never weld on a pressurized cylinder or explosion will occur.
- Use only correct shielding gas cylinders, regulators, hoses and fittings designed for the specific application; maintain them and all related components in good condition.
- Keep protective cap in place over valve except when cylinder is in use.
- Use proper equipment, procedures and have adequate help when moving or lifting cylinders.



⚠ CAUTION HOT METAL & TOOLS WILL BURN!

- Electric welding heats metal and tools to temperatures that will cause severe burns!
- Use protective, heat resistant gloves and clothing when using Eastwood or any other welding equipment. Never touch welded work surface, torch tip or nozzle until they have completely cooled.



⚠ WARNING ARC RAYS CAN BURN!

- Arc rays produce intense ultraviolet radiation which can burn exposed skin and cause eye damage. Use a shield with the proper filter (a minimum of #11) to protect your eyes from sparks and the rays of the arc when welding or when observing open arc welding (see ANSI Z49.1 and Z87.1 for safety standards).
- Use suitable clothing made from durable flame-resistant material to protect your skin.
- If other persons or pets are in the area of welding, use welding screens to protect bystanders from sparks and arc rays.



⚠ CAUTION FLYING METAL CHIPS CAN CAUSE INJURY!

- Grinding and sanding will eject metal chips, dust, debris and sparks at high velocity. To prevent eye injury wear approved safety glasses.
- Wear an OSHA-approved respirator when grinding or sanding.
- Read all manuals included with specific grinders, sanders or other power tools used before and after the welding process. Be aware of all power tool safety warnings.

REQUIRED ITEMS

Before you begin using the Eastwood TIG 200 DC, make sure you have the following:

- A properly grounded 110-120 VAC 50/60 Hz. 20 Amp Circuit or a 220-240 VAC 50/60 Hz. 30-50 Amp Circuit.
NOTE: Unit must be grounded to work properly and safely!
- A clean, safe, well-lit, dry, and well-ventilated work area.
- A non-flammable, long sleeve shirt or jacket (Eastwood #12762).
- Heavy-Duty Welding Gloves (#12590)
- An Auto Darkening Welding Mask to provide eye protection during welding operations.
NOTE: MUST be a #10 lens or darker.
- A compressed gas cylinder containing 100% Argon (must be used when TIG welding and is available at any welding supply facility).
- Dedicated stainless steel wire welding brushes for each material to be welded.
- A dedicated fine grit synthetic stone grinding wheel or a Tungsten Sharpener.



BEFORE YOU BEGIN

Remove all items from the box. Compare with list below to make sure unit is complete.

- (1) Eastwood TIG 200 DC Welder with NEMA6-50P Plug
- (1) Shielding Gas Regulator
- (1) Shielding Gas Hose
- (1) Ground Cable with Clamp (10')
- (1) WP #17 TIG Torch (14')
- (1) Foot Pedal for Amperage Control
- (1) 110-120 VAC to 220-240 VAC Adaptor Plug
- (1) Instruction Manual
- (1) Hand Held Shield
- (1) Hammer/Brush
- (1) #7 Gas Nozzle (7/16")
- (1) #6 Gas Nozzle (3/8")
- (1) #5 Gas Nozzle (5/16") (Installed)
- (1) Long Back Cap
- (1) Short Back Cap (Installed)
- (1) 3/32" Collet Body (Installed)
- (1) 3/32" Collet (Installed)
- (1) 1/16" Collet
- (1) 2.0mm Collet
- (1) 1/16" Red Thoriated Tungsten

COMPONENTS AND CONTROLS

- Power Switch** – The Power Switch is located at the left of the front panel (**FIG A**).
- Amperage (Front Panel)** – Set the Output Amperage Knob marked “A” (**FIG. A**) located at right of the front panel to an appropriate setting based on the thickness and type of the metal being welded. (**Refer to Data Chart for actual settings**).
- Amperage (Foot Pedal) Output** – Same operation as the panel control but is used while the foot pedal is in use (**FIG B**).
- Gas Flow** – The included regulator limits the shielding gas flow from the bottle and also displays how much gas is left in the bottle. The Gas Flow Indicator Gauge is located on the left side and is generally set between 12 to 20 SCFH. (**Refer to Data Chart for actual settings**). This is explained in further detail in the Preparing to Weld section of this manual. The gauge on the right indicates the pressure left in the tank.
- Foot Pedal/Panel Control** – The Foot Pedal/Panel Control selection switch is located in the center of the front panel and when set in the ‘Foot Pedal’ position, the Foot Pedal control is activated. When set to the ‘Panel Control’ position, the Torch Trigger is activated (**FIG. A**).
- TIG/Stick Switch** – The TIG/Stick Switch allows selection between TIG Welding or Stick Welding configuration. **NOTE: Stick Weld Torch is Not Included.**
- Torch Switch** – The switch on the torch (**FIG. C**) controls starting and stopping the arc. When using the torch switch the Amperage is set on the adjustment knob on the front panel of the welder.
- Foot Pedal** – The foot pedal is for starting and stopping the arc as well as controlling the Amperage during the weld. When using the foot pedal the Amperage is set by the adjustment knob on the side of the foot pedal (**FIG. B**).



DATA CHART (ALSO LOCATED ON TOP OF WELDER)

MATERIAL	MATERIAL THICKNESS	POLARITY	AMPERAGE	TUNGSTEN COLOR	TUNGSTEN DIA.	FILLER METAL	FILLER METAL DIA.	PRE FLOW (sec)	POST FLOW (sec)	TORCH CUP SIZE	GAS FLOW RATE (scfh)	CLEARANCE EFFECT
Aluminum	1/16"	AC	55-75	Green, Purple	1/16"	4043	1/16"	0.4	5	1/4 - 3/8"	15	-3 to 0
Aluminum	3/32"	AC	70-100	Green, Purple	1/16"	4043	1/16"	0.4	5	1/4 - 3/8"	15	-3 to 0
Aluminum	1/8"	AC	90-140	Green, Purple	3/32"	4043	3/32"	0.4	6	3/8 - 7/16"	17	-3 to 0
Aluminum	3/16"	AC	125-180	Green, Purple	3/32"	4043	3/32"	0.4	6	7/16 - 1/2"	21	-3 to 0
Steel	1/16"	DC-	45-80	Gray, Red, White, Purple	1/16"	ER70S-2	1/16"	0.4	5	1/4 - 3/8"	12	0
Steel	3/32"	DC-	70-110	Gray, Red, White, Purple	1/16"	ER70S-2	1/16"	0.4	5	1/4 - 3/8"	12	0
Steel	1/8"	DC-	75-125	Gray, Red, White, Purple	1/16"	ER70S-2	3/32"	0.4	6	1/4 - 3/8"	12	0
Steel	3/16"	DC-	110-200	Gray, Red, White, Purple	3/32"	ER70S-2	1/8"	0.4	6	1/4 - 3/8"	14	0
Stainless Steel	1/16"	DC-	50-90	Gray, Red, White, Purple	1/16"	ER308/308L	1/16"	0.4	5	1/4 - 3/8"	12	0
Stainless Steel	3/32"	DC-	80-120	Gray, Red, White, Purple	1/16"	ER308/308L	1/16"	0.4	5	1/4 - 3/8"	12	0
Stainless Steel	1/8"	DC-	85-140	Gray, Red, White, Purple	1/16"	ER308/308L	3/32"	0.4	6	1/4 - 3/8"	12	0
Stainless Steel	3/16"	DC-	125-200	Gray, Red, White, Purple	3/32"	ER308/308L	1/8"	0.4	6	1/4 - 3/8"	14	0


SETUP

SHIELDING GAS CONNECTION

⚠ WARNING BUILDUP OF GAS CAN INJURE OR KILL!
Shut off shielding gas supply when not in use.
Ensure adequate ventilation. Do not weld in confined spaces.
Always turn your face away from valve outlet when opening cylinder valve.

A Shielding Gas Bottle is not included with your Eastwood TIG 200 DC but is necessary while TIG welding. A Shielding Gas Bottle can be bought at most local Welding Supply Stores. Eastwood recommends the use of 100% Argon shielding gas when TIG welding Steel and Stainless Steel.


1. Place the Eastwood TIG 200 DC in its dedicated area or on a welding cart.
2. Secure your Shielding Gas Bottle to a stationary object or mount to your welding cart if it is equipped to hold one so that the cylinder cannot fall over.
3. Remove the cap from the Shielding Gas Bottle.
4. Insert the large brass male fitting on the Shielding Gas Regulator into the female fitting on the Shielding Gas Bottle (**FIG. D**).
5. Tighten the fitting with a wrench till snug, do not over tighten.
6. Connect either end of the Gas Line included with your Eastwood TIG 200 DC to the fitting on the regulator and tighten with a wrench until snug.
7. Connect the other end of the gas line to the fitting on the rear of the Eastwood TIG 200 DC and tighten with a wrench until snug (**FIG. E**).



TIG TORCH CONNECTION

⚠ WARNING ELECTRIC SHOCK CAN CAUSE INJURY OR DEATH!
Disconnect Welder from power supply before assembly or disassembly of Torch and Cables.

1. Install the plastic connection cover onto the brass torch fitting on the torch cable.
2. Connect the female brass fitting on the torch cable to the male brass fitting on the welder (**FIG. F**).
3. Use a wrench and tighten until snug. **DO NOT OVERTIGHTEN.**
4. Connect the metal plug to the Torch Switch Connection as shown (**FIG. F**).
NOTE: Omit this step if you will be using the foot pedal for Amperage control



GROUND CABLE CONNECTION

1. Locate the Ground Cable and Clamp.
2. The RED Ground Cable connection is located at the far right of the front panel as shown (**FIG. F**). With the Key on the connector in the 12 O'clock position, insert the connector and turn 180° clockwise to lock the connector in.

FOOT PEDAL CONNECTION

1. If you are going to be using the switch on the torch to start the welding arc, omit this step.
2. Connect the metal plug on the Foot Pedal to the Switch Connection as shown (**FIG. F**).

STICK WELD CONNECTION WITH OPTIONAL 20517 EASTWOOD ELECTRODE HOLDER


1. Disconnect and remove the TIG Torch/Foot Pedal Connections if in place.
2. Insert the BLACK Stick Weld Connector into the BLACK Stick Weld Connection located at the far left of the Front Panel (**FIG. F**). With the Key of the Connector at the 12:00 position, push in and rotate 180° Clockwise to lock the connector in.
3. Insert the RED Ground Connector into the RED Ground Connection located at the far right of the Front Panel (**FIG. F**). With the Key of the Connector at the 12:00 position, push in and rotate 180° Clockwise to lock the connector in. **NOTE:** The above connections are the standard default for Stick Welding. If your material or rod preference dictates it, the Stick Weld and Ground Connections may safely be reversed.

PREPARING TO TIG WELD

TORCH DISASSEMBLY

⚠ WARNING **ELECTRIC SHOCK CAN CAUSE INJURY OR DEATH!**
Disconnect Welder from power supply before assembly or disassembly of Torch and Cables.

1. Make sure the welder is turned off and unplugged.
2. Remove the back cap from the torch.
3. If there is a tungsten installed in the torch pull it out of the front of the torch.
4. Slide the collet out of the torch.
5. Unscrew and remove the gas nozzle.
6. Unscrew and remove the collet body.



TORCH ASSEMBLY

1. Select a collet body that matches your tungsten diameter size and thread it back into the front of the torch.
2. Select a collet that matches your tungsten diameter size. Insert the tungsten into the collet and put the collet and tungsten back into the torch.
3. The nozzle size should be changed according to shielding gas requirements for the material being welded. This size can be referenced on the suggested settings chart. Select the correct gas nozzle and thread it onto the collet body.
4. Reinstall the back cap to lock the tungsten in place. Always make sure the tungsten protrudes 1/8" to 1/4" beyond the gas nozzle.



SHARPENING THE TUNGSTEN

To avoid contamination of the Tungsten and ultimately the weld, it is imperative to have a dedicated grinding wheel used for Tungsten grinding only. A fine grit standard 6" synthetic stone grinding wheel on a bench top grinder is sufficient or specifically designed Tungsten Grinders are available.

1. Shut off the welder.
2. Make sure the Tungsten and Torch are sufficiently cooled for handling then loosen and remove the Back Cap, then the Collet (**FIG. G**) and remove the Tungsten from the FRONT of the Torch only (Removing from the rear will damage the Collet).

⚠ CAUTION **FLYING METAL CHIPS CAN CAUSE INJURY!**
Grinding and sanding will eject metal chips, dust, debris and sparks at high velocity. To prevent eye injury wear approved safety glasses.
Wear an OSHA-approved respirator when grinding or sanding.
Read all manuals included with specific grinders, sanders or other power tools used before and after the welding process. Be aware of all power tool safety warnings.

3. If the tungsten is used and the end is contaminated, use pliers or a suitable tool to grip the tungsten above the contaminated section and snap off the end of the Tungsten.
4. Holding the Tungsten tangent to the surface of the grinding wheel, rotate the tungsten while exerting light pressure until a suitable point is formed (**FIG. H**).
5. The ideal tip will have the length of the conical portion of the sharpened area at 2-1/2 times the Tungsten rod diameter (**FIG. I**).
6. Replace the Tungsten in the Collet with the tip extending 1/8"-1/4" beyond the Gas Nozzle, then re-tighten the Back Cap.



SETTINGS SELECTION

With the materials selected of which you will be welding you can begin to set up the welder for the specific material.

1. **Foot Pedal / Panel Control** – Determine whether you will be using the switch on the torch or the foot pedal for arc starting and stopping and put the selector switch in the appropriate position. Note that some connections changes will be necessary also when switching the control type. These connection changes are covered in the Set-Up section of this manual.
2. **Amperage** – If welding using the switch on the torch to control the arc, set the Output Amperage Knob marked “A” (**FIG. A**) located at upper left of the top panel to an appropriate setting based on the thickness and type of the metal being welded (**Refer to Data Chart for actual settings**). If welding using the foot pedal to control the arc, it uses the same operation as the panel control but is adjusted on the side of the foot pedal rather than the front panel (**FIG. B**).
3. **Power Switch** – Once all of the settings have been selected and the torch assembled and ready to use, the welder can be plugged in and turned on.
4. **Shielding Gas Flow** – Set the Gas Flow Rate to the appropriate value with the Knob located at the left side of the regulator.

SHIELDING GAS FLOW ADJUSTMENT

⚠ WARNING BUILDUP OF GAS CAN INJURE OR KILL!
Shut off shielding gas supply when not in use.
Ensure adequate ventilation. Do not weld in confined spaces.
Always turn your face away from valve outlet when opening cylinder valve.

After connecting your Shielding Gas Regulator, the gas flow rate needs to be adjusted so that the proper amount of Shielding Gas is flowing over your weld. If there is too little gas flow there will be porosity in your welds as well as excessive spatter, if there is too much gas flow you will be wasting gas and may affect the weld quality. The included regulator has 2 gauges on it; the gauge on the left is your flow rate while the gauge on your right is your tank pressure.

1. Open your Shielding Gas tank valve all the way.
2. Adjust the knob on the regulator to ~20 CFH.
3. Turn on the welder and trigger the torch switch which will start the gas flow.
4. As you trigger the torch switch you will notice that as the gas flow starts, the needle on the gauge drops to a steady reading. The reading while flowing is the value you want to read.
5. The gas flow should be set to 12-20 CFH while flowing. The CFH (Cubic Feet per Hour) scale is the inside scale in red on your flow gauge. 20 CFH is the most typical flow rate but it may need to be adjusted in some cases depending if there is a slight breeze or some other instance where additional shielding gas is required to prevent porosity in the weld.
6. When finished welding remember to close the gas valve on the bottle.

TIG WELDING

IMPORTANT NOTE: These instructions are intended only to provide the user with some familiarity of the Eastwood TIG 200 DC. TIG welding is a highly complex procedure with many variables. If you have no experience with TIG welding; it is extremely important to seek the advice of someone experienced in TIG welding for instruction, enroll in a local technical school welding course or study a comprehensive how-to DVD and obtain a good quality reference book on TIG welding as there is a moderate learning curve necessary before achieving proficiency in TIG Welding. Before attempting to use this unit on an actual project or object of value, practice on a similar material as there are many variables present and settings required when TIG welding different metals such as steel and stainless steel. It is also strongly recommended that the user adhere to the American Welding Society guidelines, codes and applications prior to producing welds where safety is affected.

⚠ WARNING WELDING SPARKS CAN CAUSE FIRE OR EXPLOSION!

Electric welding produces sparks which can be discharged considerable distances at high velocity igniting flammable or exploding vapors and materials.

Do not operate electric arc welder in areas where flammable or explosive vapors are present.

Do not use near combustible surfaces. Remove all flammable items within 35 feet of the welding area.

Always keep a fire extinguisher nearby while welding.

Use welding blankets to protect painted and or flammable surfaces; rubber weather-stripping, dash boards, engines, etc.

Ensure power supply has properly rated wiring to handle power usage.

⚠ WARNING FUMES & WELDING GASES CAN BE A HEALTH HAZARD!

Fumes and gasses released during welding are hazardous. Do not breathe fumes that are produced by the welding operation.

Wear an OSHA-approved respirator when welding.

Always work in a properly ventilated area.

Never weld coated materials including but not limited to: cadmium plated, galvanized, lead based paints.

⚠ WARNING ELECTRIC SHOCK CAN CAUSE INJURY OR DEATH!

Improper use of an electric welder can cause electric shock, injury and death! Read all precautions described in the Welder Manual to reduce the possibility of electric shock.

Disconnect welder from power supply before assembly, disassembly or maintenance of the torch, contact tip and when installing or removing nozzles.

Always wear dry, protective clothing and leather welding gloves and insulated footwear. Use suitable clothing made from durable flame-resistant material to protect your skin.

If other persons or pets are in the area of welding, use welding screens to protect bystanders from sparks.

Always operate the welder in a clean, dry, well ventilated area. Do not operate the welder in humid, wet, rainy or poorly ventilated areas.

The electrode and work (or ground) circuits are electrically "hot" when the welder is on. Do not allow these "hot" parts to come in contact with your bare skin or wet clothing.

Separate yourself from the welding circuit by using insulating mats to prevent contact from the work surface.

Be sure that the work piece is properly supported and grounded prior to beginning an electric welding operation.

Always attach the ground clamp to the piece to be welded and as close to the weld area as possible. This will give the least resistance and best weld.

⚠ CAUTION HOT METAL & TOOLS WILL BURN!

Electric welding heats metal and tools to temperatures that will cause severe burns!

Use protective, heat resistant gloves and clothing when using Eastwood or any other welding equipment. Never touch welded work surface, torch tip or nozzle until they have completely cooled.



⚠ WARNING ARC RAYS CAN BURN!

Arc rays produce intense ultraviolet radiation which can burn exposed skin and cause eye damage. Use a shield with the proper filter (a minimum of #11) to protect your eyes from sparks and the rays of the arc when welding or when observing open arc welding (see ANSI Z49.1 and Z87.1 for safety standards).

Use suitable clothing made from durable flame-resistant material to protect your skin.

If other persons or pets are in the area of welding, use welding screens to protect bystanders from sparks and arc rays.

1. Turn the Power Switch to the on position.
2. Slowly open the gas cylinder valve.
NOTE: Always open valve fully to avoid shielding gas leakage.
3. Depress gun trigger switch or foot pedal and adjust the flow regulator.
(Refer to Data Chart for actual settings).
4. Grounding is very important, place the Ground Cable Clamp on a clean, bare area of your work piece as close to the welding area as possible to minimize the chance of shock. Scrape, wire brush, file or grind a bare area to achieve a good ground to assure safety.
5. Use a dedicated stainless steel brush or flap-disc to clean the areas to be welded. Do not use the brush or flap-disc for any other purpose.
6. Making sure all your safety gear is in place (Welding Mask, Welding Gloves, non-flammable long sleeve apparel) and the area is completely free of flammable material.
7. Although it is a matter of developing a personal style, a good starting point for best results is achieved by holding the tip at a 75° angle backward and approx. 20° opposing the direction of travel. Hold the Filler Metal Rod at a 90° angle to the Tungsten Tip (**FIG. J**). Never allow the Tungsten Tip to touch the welding surface or material rod. Doing so will quickly destroy the tip and contaminate the weld. If this happens, remove the Tungsten and regrind the tip. It is best to hold the tungsten tip 1/8" from the surface.
8. With your Welding Shield and all safety gear in place, depress the foot pedal or trigger and practice "Forming A Puddle" with the Tungsten Tip. Once you become familiar with this step. Practice the "Dip and Pull" technique with the Filler Metal Rod and Torch. "Dip and Pull" is the practice of forming a puddle, moving the torch while maintaining the puddle and adding filler rod metal to the puddle by "dipping and pulling" as you go; being careful not to allow the tungsten to contact the puddle or rod.
9. Keep in mind that you **MUST** let the shielding gas flow over the weld after releasing the trigger or pedal. Failure to do so will allow the welded area to oxidize compromising the weld integrity.
10. Constantly be aware that TIG welding quickly generates heat in the work piece and torch. Severe burns can quickly occur by contacting hot metal pieces.
11. When done, shut off the Power Switch and close the Shielding Gas Tank valve completely.



WELDER CARE & MAINTENANCE

- Constantly inspect the torch tip for excessive erosion, molten metal accumulation burning. If damaged, it must be replaced.
- Before each use, inspect ALL electrical connections, cables, supply line, torch, air supply, housing and controls for damage. If any damage or wear is noted, DO NOT USE THE UNIT.
- If the welder requires service, it should be performed by a certified repair facility using only authorized replacement parts to maintain full safety and performance integrity of the welder.
- Always store the unit in a safe, clean and dry environment.

TORCH MAINTENANCE

The Eastwood TIG 200 has a number of consumable parts that will need to be replaced over time. If wear or slag build up is noticed on any of the torch components, replace them immediately to avoid damage to the torch. Worn components will also contribute to poor performance. See the torch components (FIG. G) exploded view for a reference of all of the components and the assembly order.

⚠ WARNING ELECTRIC SHOCK CAN CAUSE INJURY OR DEATH!

Disconnect welder from power supply before assembly, disassembly or maintenance of the torch, contact tip and when installing or removing nozzles.

TIG TROUBLESHOOTING

Arc is triggered but will not start	Incomplete Circuit	Check Ground connection. Make sure that the ground is on a freshly cleaned surface and close to the welding area. It is suggested to weld towards the ground connection.
	Incorrect Tungsten	Consult chart for proper tungsten for the base metal being welded. In most cases E ³ will be used for all steels.
	No shielding gas	Make sure the shielding gas cylinder is turned all the way open and set at the correct flow rate.
Arc wanders and it is hard to concentrate heat in a specific area	Poorly prepped tungsten	Follow guidelines for prepping tungsten.
	Poor Gas Flow	Adjust the flow rate of the shielding gas (refer to settings chart). Check for loose fittings where gas could be leaking.
	Contaminated Tungsten	Remove tungsten from torch and break off contaminated section and sharpen.
	Incorrect arc length	Make sure the tungsten is held 1/8 to 1/4 inch off the work piece.
	Incomplete circuit	Check Ground connection. Make sure that the ground is on a freshly cleaned surface and close to the welding area. It is suggested to weld towards the ground connection.
	Contaminated base metal	Clean base metal making sure to remove any oil, debris, coatings, or moisture.

TIG TROUBLESHOOTING

Porosity in weld bead	Poor Gas Flow	Adjust the flow rate of the shielding gas (refer to settings chart). Check for loose fittings where gas could be leaking.
	Contaminated filler metal	Clean filler metal making sure to remove any oil, debris, or moisture.
	Contaminated base metal	Clean base metal making sure to remove any oil, debris, coatings, or moisture.
	Poor Shielding	Make sure to be in an area with no wind and with any fans turned off. Wind or fans will blow the shielding gas away from the weld causing porosity.
	Incorrect Tungsten Stick Out	Adjust the tungsten so that 1/8 to 1/4 inch is sticking out of the collet.
Contamination in weld bead	Contaminated Tungsten	Remove tungsten from torch and break off contaminated section and sharpen.
	Contaminated Filler Metal	Clean filler metal making sure to remove any oil, debris, or moisture.
	Contaminated Base Metal	Clean base metal making sure to remove any oil, debris, coatings, or moisture. If base metal is cold rolled steel make sure to remove any mill scale.
Melting Tungsten	Poor Gas Flow	Adjust the flow rate of the shielding gas (refer to settings chart). Check for loose fittings where gas could be leaking.
	Wrong Size Tungsten	Increase tungsten diameter. Refer to chart for proper sizing.
	Incorrect Shielding Gas	Only use 100% Argon when TIG Welding.
Poor Penetration	Low Voltage	Voltage setting is too low for material/thickness. Increase as needed and reference chart on welder.
Tungsten Contaminated	Contact of Tungsten with Base Metal	Keep tungsten 1/8 to 1/4 inch from the base metal. If tungsten comes in contact break off end and sharpen immediately.
Poor Weld Appearance	Incorrect positioning	The angle between the filler metal and the torch must be less than 90 degrees otherwise the filler metal will prematurely melt and glob off causing poor weld appearance.

TIG TROUBLESHOOTING

Crater in the End of the Weld Bead	Insufficient Shielding	Keep the torch on the base metal while the post flow shielding gas flows to protect and cool the metal and tungsten.
	Not Enough Filler Material	Reduce current with pedal and add more filler at end of weld. It may also be beneficial to back step to ensure no crater will form.
Weld Bead is Cracking	Too much heat in material	Reduce heat and allow more time between passes.
	Base Metal is absorbing too much heat	Preheat base metal (consult welding codes for requirements)
	Incorrect Filler Wire	Use appropriate filler wire type and diameter for the joint being welded.
Material is Warping	Insufficient Clamping	Clamp work piece tightly and weld while clamps are in place.
	Insufficient Tack Welds	Add more tack welds until rigidity and stiffness is developed.
	Too Much Heat in Material	To reduce heat it is best to spread the welding out around the area. This can be done by using stitch welding techniques, alternating sides, and/or taking your time and allowing the pieces to cool between passes.

STICK WELDING

⚠ WARNING WELDING SPARKS CAN CAUSE FIRE OR EXPLOSION!

Electric welding produces sparks which can be discharged considerable distances at high velocity igniting flammable or exploding vapors and materials.

Do not operate electric arc welder in areas where flammable or explosive vapors are present.

Do not use near combustible surfaces. Remove all flammable items within 35 feet of the welding area.

Always keep a fire extinguisher nearby while welding.

Use welding blankets to protect painted and or flammable surfaces; rubber weather-stripping, dash boards, engines, etc.

Ensure power supply has properly rated wiring to handle power usage.

⚠ WARNING FUMES & WELDING GASES CAN BE A HEALTH HAZARD!

Fumes and gasses released during welding are hazardous. Do not breathe fumes that are produced by the welding operation.

Wear an OSHA-approved respirator when welding.

Always work in a properly ventilated area.

Never weld coated materials including but not limited to: cadmium plated, galvanized, lead based paints.

⚠ WARNING ELECTRIC SHOCK CAN CAUSE INJURY OR DEATH!

Improper use of an electric welder can cause electric shock, injury and death! Read all precautions described in the Welder Manual to reduce the possibility of electric shock.

Disconnect welder from power supply before assembly, disassembly or maintenance of the torch, contact tip and when installing or removing nozzles.

Always wear dry, protective clothing and leather welding gloves and insulated footwear. Use suitable clothing made from durable flame-resistant material to protect your skin.

If other persons or pets are in the area of welding, use welding screens to protect bystanders from sparks.

Always operate the welder in a clean, dry, well ventilated area. Do not operate the welder in humid, wet, rainy or poorly ventilated areas.

The electrode and work (or ground) circuits are electrically "hot" when the welder is on. Do not allow these "hot" parts to come in contact with your bare skin or wet clothing.

Separate yourself from the welding circuit by using insulating mats to prevent contact from the work surface.

Be sure that the work piece is properly supported and grounded prior to beginning an electric welding operation.

Always attach the ground clamp to the piece to be welded and as close to the weld area as possible. This will give the least resistance and best weld.

⚠ CAUTION HOT METAL & TOOLS WILL BURN!

Electric welding heats metal and tools to temperatures that will cause severe burns!

Use protective, heat resistant gloves and clothing when using Eastwood or any other welding equipment. Never touch welded work surface, torch tip or nozzle until they have completely cooled.

⚠ WARNING ARC RAYS CAN BURN!

Arc rays produce intense ultraviolet radiation which can burn exposed skin and cause eye damage. Use a shield with the proper filter (a minimum of #11) to protect your eyes from sparks and the rays of the arc when welding or when observing open arc welding (see ANSI Z49.1 and Z87.1 for safety standards).

Use suitable clothing made from durable flame-resistant material to protect your skin.

If other persons or pets are in the area of welding, use welding screens to protect bystanders from sparks and arc rays.

1. Plug the power cord into a properly grounded, 110-120 Volt AC, 50/60Hz, 20 Amp or a 220-240 Volt AC 50/60Hz. 30-50 Amp circuit.
2. Move the TIG/Stick Switch to the "Stick" position.
3. Make sure the Electrode or "Stick" **is not making contact with the grounded workpiece.**
4. Switch the Power Switch to "On".
5. While wearing a properly functioning Auto Darkening Welding Helmet, Lightly drag the tip of the Welding Rod along the workpiece surface to start an arc.
6. Feed the Welding Rod into the workpiece joint at a 15° angle.
7. Lift rod from workpiece when weld bead is completed.
8. Turn off Welder power switch.
9. Set the Electrode or "Stick" Holder on a safe, non-flammable, surface.

ACCESSORIES

TIG WELDING SUPPLIES:

- #12253 ER70S-2 Steel TIG Wire 1/16-36"
- #12254 ER70S-2 Steel TIG Wire 3/32-36"
- #12463 308L Stainless TIG Wire 1/16-36"
- #12464 308L Stainless TIG Wire 3/32-36"
- #20176 E3 Tungsten (Purple) 1/16-7" 2pc
- #20177 E3 Tungsten (Purple) 3/32-7" 2pc

REPLACEMENT ITEMS:

- #13483 TIG 200 Collet Body (1.6mm; 1/16")
- #13484 TIG 200 Collet Body (2.4mm; 3/32")
- #12822 TIG 200 Collet (1.6mm; 1/16")
- #12824 TIG 200 Collet (2.4mm; 3/32")
- #12825 TIG 200 Long Back Cap
- #12819 TIG 200 Gas Nozzle (9.8mm; 3/8")
- #12821 TIG 200 Gas Nozzle (11.2mm; 1/2")
- #13953 TIG Accessory Kit

OTHER WELDING ACCESSORIES:

- #20493 Upgraded Foot Pedal
- #11947 Flap Disc 60 Grit 4.5" Diameter 7/8" Hole
- #12590 Welding Gloves Large
- #12589 Welding Gloves Medium
- #13203 Auto Darkening Welding Helmet
- #13212 Large View Auto Darken Welding Helmet
- #20189 Extra-Large-View Auto Darkening Welding Helmet
- #19079S Stainless Steel Brush
- #12762 L, XL, XXL Welding Jacket
- #21524 TIG Welding Basics DVD by Ron Covell
- #11616 TIG 200 Welding Cart
- #14106 Welding Table
- #20517 Stick Electrode Holder

If you have any questions about the use of this product, please contact

The Eastwood Technical Assistance Service Department: 800.544.5118 >> email: techelp@eastwood.com
PDF version of this manual is available online >> eastwood.com/20566manual

The Eastwood Company 263 Shoemaker Road, Pottstown, PA 19464, USA
US and Canada: 800.345.1178 Outside US: 610.718.8335
Fax: 610.323.6268 eastwood.com