## STEERING WHEEL REPAIR KIT

## **INSTRUCTIONS**

- **1.** Review vehicle service manual to remove steering wheel from vehicle.
- 2. Wash the steering wheel with dishwashing detergent and water.
- **3.** Wipe down steering wheel with PRE Painting Prep repeatedly with clean rags until surface is clean.
- 4. Use a triangular file to "V" out any cracks down to the metal frame. Filling narrow cracks without "V"ing out will lead to early failure. The PC-7 will easily fill the widened repair area.
- **5.** Mix PC-7 per label instructions and apply, slightly overfilling the repair areas.
- **6.** Dip your finger in water and smooth the repair immediately after application. This should minimize sanding and yield a smooth surface.
- **7.** Allow the repairs to fully harden overnight.
- **8.** Sand repair area(s) with 220 grit wet or dry paper and finish up with 320 grit.
- **9.** Wipe wheel thoroughly with PRE Painting Prep and allow to dry. DO NOT handle cleaned steering wheel with bare hands, use disposable gloves.
- **10.** Following label instructions, apply several light coats of Adhesion Promoter to entire steering wheel.
- 11. Apply finish of choice within 30 minutes.

## If you have any questions about the use of this product, please contact