

Item #31475

DAMAGED LUG NUT REMOVAL SOCKETS

INSTRUCTIONS



The **EASTWOOD DAMAGED LUG NUT REMOVAL SOCKETS** fit three of the most popular sized lug nuts in 17mm, 19mm & 21mm dimensions by cutting into rounded hex surfaces (will also fit 5/8", 3/4" & 13/16" dimensions).

SAFETY INFORMATION

The following explanations are displayed in this manual, on the labeling, and on all other information provided with this product:

A DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

A WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

A CAUTION

CAUTION used with the safety alert symbol, indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

A NOTICE

NOTICE is used to address practices not related to personal injury.



A READ INSTRUCTIONS

- Thoroughly read and understand these product instructions before using the Damaged Lug Nut Removal Sockets.
- Keep these product instructions for future reference.



A WARNING

IMPROPER MOTOR VEHICLE REPAIR WORK CAN RESULT IN INJURY OR DEATH!

 Performing automotive repair work can cause injury, death and vehicle accidents. DO NOT attempt to use this tool or begin work without proper training and a thorough understanding of motor vehicle mechanical systems.



A WARNING

IMPROPER VEHICLE JACKING CAN RESULT IN INJURY OR DEATH!

 Always consult an authorized manufacturer's service manual or reference materials on the particular vehicle under repair for the proper jacking procedures.



A WARNING CUT HAZARD!

 Produces sharp edges. Wear heavy work gloves while handling Removal Sockets and damaged lug nuts.



A CAUTION EYE INJURY HAZARD!

Chips or particles may be ejected from components causing eye injury.
Wear ANSI approved eye protection while using.



A CAUTION FALL HAZARD!

 Components may suddenly shift while being operated. Failure to ensure proper footing can quickly result in a fall which could inflict serious personal injury or property damage.

OPERATION:

- Select the Removal Socket that fits the damaged lug nut to be removed.
- Place Removal Socket over damaged lug nut and remove in normal way.

NOTE:

- Use of the matching size Removal Socket may round off damaged lug nut corners causing Removal Socket to spin freely. Should this occur, use the next smallest Removal Socket size.
- Use to remove lug nuts that employ right-hand thread only.
- Do Not use to tighten lug nuts.
- Do Not re-use lug nuts that have been removed using this tool.

| | If you have any questions about the use of this product, please contact |
|------------|--|
| The Eastwo | If you have any questions about the use of this product, please contact od Technical Assistance Service Department: 800.343.9353 >>> email: techelp@eastwood.com |
| The Eastwo | |
| The Eastwo | od Technical Assistance Service Department: 800.343.9353 >> email: techelp@eastwood.com |
| The Eastwo | od Technical Assistance Service Department: 800.343.9353 >> email: techelp@eastwood.com PDF version of this manual is available online >> eastwood.com/31475manual |
| The Eastwo | od Technical Assistance Service Department: 800.343.9353 >> email: techelp@eastwood.com PDF version of this manual is available online >> eastwood.com/31475manual The Eastwood Company 263 Shoemaker Road, Pottstown, PA 19464, USA US and Canada: 800.343.9353 Outside US: 610.718.8335 |
| The Eastwo | od Technical Assistance Service Department: 800.343.9353 >> email: techelp@eastwood.com PDF version of this manual is available online >> eastwood.com/31475manual The Eastwood Company 263 Shoemaker Road, Pottstown, PA 19464, USA |