

Eastwood[®]

DO THE JOB RIGHT.[®]

Item #31879

COB LED RECHARGEABLE FLOOD LIGHT

INSTRUCTIONS



The **EASTWOOD COB LED RECHARGEABLE FLOOD LIGHT** utilizes the latest LED technology to achieve the brightest output and most energy efficiency possible. A solid cast aluminum housing with rubber shock resistant protection provides tactical level reliability.

CONTENTS

- (1) Work Light
- (1) USB Charging Cable
- (1) USB Output Wall Charger

FEATURES

- Three function Switch:
 - One, Low Illumination
 - Two, High Illumination
 - Three, Off
- 180° rotating stand.
- Power bank 5 Volt, 1 Amp USB output function can charge mobile devices
- Battery power display function: 4 blue LED's indicate charge level
- Durable aluminum housing with rubber coated grips
- 30" USB Charging Cable
- 5 Volt, 1 Amp USB output AC wall charger

SPECIFICATIONS

- 3.7 Volt, 4400mAh Integral Rechargeable Battery
- 1200 Lumens light output (high), 400 Lumens light output (low)
- 3 hours working time (high), 6 hours working time (low)
- 6 hour charge time
- Moisture resistant to IP-54 rating

SAFETY INFORMATION

The following explanations are displayed in this manual, on the labeling, and on all other information provided with this product:

DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

WARNING


WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION

CAUTION used with the safety alert symbol, indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.


NOTICE

NOTICE is used to address practices not related to personal injury.



READ INSTRUCTIONS

- Thoroughly read and understand this manual before using.
- Save for future reference.



CAUTION EYE INJURY HAZARD!

- Do Not allow LED lamps to project directly into eyes.
Temporary blindness may occur.



CAUTION SHOCK HAZARD!

- Keep metal housing of work light away from live electrical sources.



NOTICE

- Keep work light away from excessive heat sources to avoid damage.

OPERATION

- Grip Handle/Stand and rotate through 180° to support or hang lamp.
- Depress Switch located at rear of housing once for Low, 2nd for High, 3rd for Off.

CHARGING

- When the Lamp fails to illuminate and/or the 4 Blue LED's at the rear of the Housing do not illuminate, a charge is required. Note that the number of illuminated LED's will decrease in number as the charge depletes.
 - Plug round terminal of included Cable into rear of Housing.
 - Plug USB end of included Cable into the included Wall Charger or other standard 5 Volt, 1 Amp USB port.
 - Allow 6 hours for full charge.
 - The array of 4 Blue LED's at the rear of the Housing will all illuminate to indicate full charge.
 - Close Charging Port Cover to maintain IP-54 rating.

POWER BANK FUNCTION

- The 5 Volt, 1 Amp USB output port may be used to charge a mobile device.
 - Fully charge the lamp battery as described in "Charging" section.
 - Plug the cable from your mobile device into the USB port on the rear of the Lamp Housing.

If you have any questions about the use of this product, please contact

The Eastwood Technical Assistance Service Department: 800.343.9353 >> email: techhelp@eastwood.com

PDF version of this manual is available at eastwood.com

The Eastwood Company 263 Shoemaker Road, Pottstown, PA 19464, USA

800.343.9353 eastwood.com