

*Eastwood*<sup>®</sup>

DO THE JOB RIGHT.<sup>®</sup>

Item #32407

# “SOLAR FLARE” COLOR MATCHING LIGHT INSTRUCTIONS



The **EASTWOOD SOLAR FLARE COLOR MATCHING LIGHT** utilizes the latest COB LED technology to provide full-spectrum light emulating pure sunlight for true color representation. A three-position switch allows instant switching from the specialized, color correcting COB LED to the high-intensity flashlight LED. A lightweight polymer housing with shock resistant protection provides tactical level reliability. The convenient swiveling and pivoting, dual-magnetic mount design allows for maximum flexibility and the USB charging cable allows connection to any USB source.

## CONTENTS

- (1) Eastwood, Solar Flare, Color Matching Light with integral auxiliary flashlight on an adjustable magnetic base and housing
- (1) Wall Charger – 120V input, 5.0VDC, 1A output with integral USB port
- (1) 39" [1m] Adapter Cord



## SPECIFICATIONS

- 3.7 Volt, 2600mAh, Li-ion, 18650 type Integral Rechargeable Battery
- 280 Lumens light output (Color Correcting COB LED), 60 Lumens light output (Flashlight)
- CRI (Color Rendering Index) > 95
- Color Temperature = 4500K
- 2 hours working time (Color Correcting COB LED), 8 hours working time (Flashlight)
- 4 hour charge time
- Moisture resistant to IP-20 rating
- USB capable recharging

## FEATURES

- Three function Switch: **(FIG 1)**
  - Press once and release, On – Color-Correcting COB LED Illumination.
  - Press again and release, Flashlight Illumination.
  - Press again and release, Off.
- Battery power display function: RED flashing LED indicates low battery.
- Magnets at Base and Housing with 360° swiveling and 180° pivoting adjustment.
- Retractable Hook in rear of Housing.



# SAFETY INFORMATION

The following explanations are displayed in this manual, on the labeling, and on all other information provided with this product:

## DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

## WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

## CAUTION

CAUTION used with the safety alert symbol, indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.


## NOTICE

NOTICE is used to address practices not related to personal injury.



## WARNING

**LITHIUM BATTERIES STORE A LARGE AMOUNT OF ENERGY AND WILL ERUPT IN FLAMES OR VIOLENTLY EXPLODE IF NOT PROPERLY HANDLED.**



## READ INSTRUCTIONS

- Thoroughly read and understand this manual before using.
- Save for future reference.



## WARNING **SERIOUS INJURY, FIRE & EXPLOSION HAZARD!**

- Keep Dry. Do Not open unit, drop, short circuit, incinerate, expose to temperatures greater than 140°F [60°C].
- Do Not charge or use if damaged.
- Do Not submerge lamp.
- Do Not operate in explosive atmospheres such as explosive vapors, flammable liquids, gasses or dust.
- Not a toy. Keep out of the reach of children.
- Charge lamp only according to these instructions.



## CAUTION **EYE INJURY HAZARD!**

- DO NOT allow LED lamp to project directly into eyes. Temporary blindness may occur.

# OPERATION

- Grip the lamp housing and rotate Magnetic Base through 360° in the vertical and 180° horizontally on the pivoting Base (**FIG 2**).
- Place the base or rear of housing against any ferrous metal surface for magnetic attachment.
- Release Retractable Hook to hang from overhead objects.
- Depress and release round Button located at front of Housing once for Color-Correcting LED Illumination and a 2nd time for the Flashlight (**FIG 1**).
- Depress Button once again to turn off.

**FIG.2**



# CHARGING

- When the LED power indicator located at the front of the Housing flashes RED, the battery requires charging.
  - Flip up rubber seal and plug the Micro USB terminal of the included Adapter Cord into the Micro USB port.
  - Plug the opposite USB end into the USB port of the included Wall Charger or any suitable USB port (**FIG 3**).
  - Plug wall unit into properly grounded 120 VAC, 60 Hz. outlet
  - Allow 4 hours for full charge.
  - The indicator LED at the front of the Housing will illuminate RED while charging then change to GREEN indicating full charge (**FIG 1**).
  - Close Charging Port Cover to maintain IP-20 rating.



## **▲ NOTICE**

**Batteries will slowly discharge without use and must be charged every 3 months even if the light has not been used.  
Do Not charge batteries in temperatures below 40°F [4.4°C].**

**If you have any questions about the use of this product, please contact**

The Eastwood Technical Assistance Service Department: 800.343.9353 >> email: [techelp@eastwood.com](mailto:techelp@eastwood.com)

PDF version of this manual is available at [eastwood.com](http://eastwood.com)

The Eastwood Company 263 Shoemaker Road, Pottstown, PA 19464, USA 800.343.9353 [eastwood.com](http://eastwood.com)

© Copyright 2018 Easthill Group, Inc. 8/18 Instruction item #32407Q Rev 2