



MP140i/MP200i WIRE GUIDE NOZZLE INSTALLATION

The Wire Guide Nozzle is supplied uninstalled to prevent possible damage in shipment. It is installed as follows:

- Remove Wire Guide Nozzle from plastic bag.
- Loosen Phillips Head Screw on Wire Feed.
- Insert black plastic portion of Wire Guide Nozzle into Wire Feed bore.
- Tighten Phillips Screw to secure the Wire Guide Nozzle in place.