

## Motor Stand with Variable-Speed Control Instructions

### Part #51135



### ⚠ WARNING

**DO NOT ATTEMPT TO OPERATE MOTOR WITHOUT SECURELY ATTACHING THE BASE TO A SECURE WORK SURFACE.**

## Set Up

- Secure Base on a flat, stable surface.
- Using the two 5/32" holes in the base, place suitable screws (not included) through holes and drive into work surface. 1" or longer screws are recommended.
- Assemble larger diameter telescoping extension tube into base and tighten retaining screw. Place smaller diameter extension tube into larger one and tighten screw. Do not exceed a total height of 26" for safe operation.
- Place cylindrical portion of swivel hook into smaller extension tube.
- Be sure the red rocker switch is in the OFF position and the "Power Guide" Knob is at the lowest "0" position then plug the cord into a grounded outlet.
- Place the Hanging Motor onto swivel hook.
- Be sure the Hanging Motor Switch is in the "OFF" position then plug the cord into the receptacle in the base.

## Operation

- Turn switch to the "On" position on the Hanging Motor.
- After making sure the speed control knob is at the lowest "0" position, turn the Red Rocker Switch on the Base to the "ON" position.
- Slowly rotate the "Power Guide" Knob clockwise and the motor shaft will begin to rotate at the "5" to "13" mark. Rotating the knob clockwise will continue to increase the motor speed.

### ⚠ CAUTION

Always turn the "Power Guide" Knob back to the "0" position, the Red Rocker Switch to the "OFF" position and the Motor Switch to the "OFF" position when completing work with the unit.

To order parts and supplies, call 1-800-345-1178 or visit [www.eastwood.com](http://www.eastwood.com)



If you have any questions about the use of this product, please contact  
The Eastwood Technical Assistance Service Department:  
1-866-759-2131 email: [techelp@eastwood.com](mailto:techelp@eastwood.com)