

Item #31724

# 7PC SENSOR SOCKET SET INSTRUCTIONS



The **EASTWOOD 7 PIECE SENSOR SOCKET SET** fits the most common sized Oxygen Sensor, Oil Pressure Sending Unit, Coolant Sensor, Injector and Vacuum Switch fittings.

#### **CONTENTS**

(1) Vacuum Switch Socket: 1/2" Drive x 1-3/16" x 3-1/2"

(1) Oxygen Sensor Socket: 3/8" Drive x 7/8" x 3-1/8"

(1) Oxygen Sensor Wrench: 3/8" Drive x 7/8" x 1-1/4"

(1) Oil Pressure Sending Unit Socket: 3/8" Drive x 1" and 1-1/16" x 3"

(1) Heated Oxygen Sensor Socket: 1/2" Drive x 7/8" x 2"

(1) Thermal Sensor Switch Socket: 1/2" Drive x 1-1/16" x 3-1/4"

(1) Oxygen Sensor Socket/Vacuum Switch Socket: 3/8" Drive x 7/8" x 3-1/2"

(1) Rugged Blow Molded Case

#### SAFETY INFORMATION

The following explanations are displayed in this manual, on the labeling, and on all other information provided with this product:

#### **A** DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

#### **A** WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

#### **A** CAUTION

CAUTION used with the safety alert symbol, indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

#### **A** NOTICE

NOTICE is used to address practices not related to personal injury.

#### SAFETY INFORMATION




#### **A** READ INSTRUCTIONS

- Thoroughly read and understand these product instructions before using the Sensor Sockets.
- Keep these product instructions for future reference.



# A WARNING IMPROPE

# IMPROPER MOTOR VEHICLE REPAIR WORK CAN RESULT IN INJURY OR DEATH HAZARD!





#### A WARNING INJURY HAZARD!

D0 N0T use with impact tools.



#### A CAUTION EYE INJURY HAZARD!

Chips or particles may be ejected from components causing eye injury.
 Wear ANSI approved eye protection while using.

#### **A CAUTION** FALL HAZARD!

 Fittings may suddenly loosen or shift while being loosened. Failure to ensure proper footing can quickly result in a fall which could inflict serious personal injury or property damage.

#### **OPERATION**

- Select the Socket that fits the fitting to be removed.
- Place Socket over fitting and remove in normal way. DO NOT use with impact tools.



#### Vacuum Switch Socket: 1/2" Drive x 1-3/16" x 3-1/2"

Removes oil pressure sending units on late 80's to mid 90's GM models.

Use with 1/2" drive tool.



## Oxygen Sensor Socket: 3/8" Drive x 7/8" x 3-1/8"

Removes and installs oxygen sensors in domestic and many import vehicles. Slot in socket for wire clearance. Use with 3/8" drive tool or a 1" wrench.



# Oxygen Sensor Wrench: 3/8" Drive x 7/8" x 1-1/4"

Low profile design for use in tight spaces.
Use with 3/8" drive tool.



## Oil Pressure Sending Unit Socket: 3/8" Drive x 1" and 1-1/16" x 3"

Removes oil pressure sending units. Deep design fits switches up to 2-5/8". Use with 3/8" drive tool or a 1-1/8" wrench.



#### Heated Oxygen Sensor Socket: 1/2" Drive x 7/8" x 2"

Slot in socket accommodates connectors on heated oxygen sensors.

Double 1/2" drive for easy access.



### Thermal Sensor Switch Socket: 1/2" Drive x 1-1/16" x 3-1/4"

Removes and installs thermal sensor switches on 1973-1977 GM vehicles. Use with 1/2" drive tool.



#### Oxygen Sensor Socket/ Vacuum Switch Socket: 3/8" Drive x 7/8" x 3-1/2"

Removes and installs vacuum switches with a 7/8" hex and some oxygen sensors. Use with 3/8" drive tool or a 1" wrench.

#### If you have any questions about the use of this product, please contact

The Eastwood Technical Assistance Service Department: 800.343.9353 >> email: tech@eastwood.com
PDF version of this manual is available at eastwood.com
The Eastwood Company 263 Shoemaker Road, Pottstown, PA 19464, USA
800.343.9353 eastwood.com